

Spill Management



1. Make a loud call notifying surrounding individuals that a spill has occurred here, and warn them not to trespass the area.



2. Wait for aerosols generated during the spill to settle, at least 3 minutes.



3. Wear personal protective equipment in spill kit i.e. thick rubber gloves, gown, mask, plastic apron.



4. Confine the liquid with boundary of tissue paper.



5. Put layers of tissue paper or absorbent pads over the spill.



6. Saturate the area with sodium hypochlorite 10,000 ppm (5 tablets of hypochlorite in 500 cc water or 100 ml of liq bleach in 5 L of water) soak for 2 min then do regular mop. Solution should be made daily.